



可换头定值扭矩扳手



注意: 仅限于
顺时针方向使用

- 符合JJG扭矩扳子国家计量检定规程
- 预设扭矩值, 避免使用时误调
- 出厂前预设扭矩值, 用户也可以设定扭矩值, 需选购对应扭力调节工具和数显扭矩仪(IST-TT□□□)
- 仅限于顺时针方向使用



扭力调节工具(选配)

IST-41WM120

技术参数

型号	扭矩调节范围*		精度	安装槽尺寸(A×B)	长度	重量
IST-41WM5	1~5N.m	10~45lb.in	±3%	12×9mm	145mm	220g
IST-41WM10	2~10N.m	20~90lb.in		12×9mm	155mm	230g
IST-41WM12	2.5~12N.m	20~105lb.in		12×9mm	200mm	340g
IST-41WM20	4~20N.m	30~180lb.in		12×9mm	240mm	400g
IST-41WM30	6~30N.m	50~250lb.in		12×9mm	240mm	400g
IST-41WM60	10~60N.m	9~45lb.ft		12×9mm	310mm	400g
IST-41WM120	25~120N.m	20~90lb.ft		12×9mm	355mm	600g
IST-41WM200	40~200N.m	30~150lb.ft		18×14mm	417mm	860g
IST-41WM340	65~340N.m	50~250lb.ft		18×14mm	681mm	1300g
IST-41WM500	100~500N.m	80~400lb.ft		32×24mm	910mm	2300g
IST-41WM650	150~650N.m	100~500lb.ft	±3% (≤500N.m) ±4% (>500N.m)	32×24mm	1030mm	2560g
IST-41WM800	160~800N.m	120~600lb.ft		32×24mm	1030mm	4800g
IST-41WM1000	200~1000N.m	150~750lb.ft		32×24mm	1260mm	5700g
IST-41WM1500	300~1500N.m	200~1100lb.ft		36×27mm	1610mm	7800g
IST-41WM2000	400~2000N.m	300~1500lb.ft		36×27mm	1910mm	9200g
IST-41WM3000	600~3000N.m	400~2200lb.ft	±4%	36×27mm	2010mm	9600g

可选配件

扭力调节工具	IST-36WM-TOOL1(适用于IST-41WM5, IST-41WM10)
	IST-36WM-TOOL2(适用于IST-41WM12, IST-41WM20, IST-41WM30, IST-41WM60, IST-41WM120)
	IST-PW-TOOL(适用于IST-41WM200, IST-41WM340, IST-41WM500, IST-41WM650, IST-41WM800, IST-41WM1000, IST-41WM1500, IST-41WM2000, IST-41WM3000)

* 根据客户需求调节至某一固定扭矩值

扭矩修正



棘轮头部(选配)

型号	棘轮方头尺寸	适用的扳手
IST-11WM-R1	1/4"	IST-41WM5, IST-41WM10, IST-41WM12, IST-41WM20, IST-41WM30
IST-11WM-R2	3/8"	IST-41WM5, IST-41WM10, IST-41WM12, IST-41WM20, IST-41WM30, IST-41WM60, IST-41WM120
IST-11WM-R3	1/2"	IST-41WM200, IST-41WM340
IST-11WM-R4	3/4"	IST-41WM200, IST-41WM340
IST-11WM-R5	3/4"	IST-41WM500, IST-41WM650, IST-41WM800, IST-41WM1000
IST-11WM-R6	1"	IST-41WM1500, IST-41WM2000, IST-41WM3000



开口扳手头部(选配)

型号	开口尺寸	适用的扳手
IST-11WM-K4	4mm	IST-41WM5 IST-41WM10 IST-41WM12 IST-41WM20 IST-41WM30 IST-41WM60 IST-41WM120 (A×B 12×9mm)
IST-11WM-K5	5mm	
IST-11WM-K5D5	5.5mm	
IST-11WM-K6	6mm	
IST-11WM-K7	7mm	
IST-11WM-K8	8mm	
IST-11WM-K9	9mm	
IST-11WM-K10	10mm	
IST-11WM-K11	11mm	
IST-11WM-K12	12mm	
IST-11WM-K13	13mm	
IST-11WM-K14	14mm	
IST-11WM-K15	15mm	
IST-11WM-K16	16mm	
IST-11WM-K17	17mm	
IST-11WM-K19*	19mm	
IST-11WM-K20*	20mm	
IST-11WM-K25*	25mm	
IST-11WM-K30*	30mm	
IST-11WM-K35*	35mm	
IST-11WM-K40*	40mm	
IST-11WM-K45*	45mm	
IST-11WM-K50*	50mm	
IST-11WM-K55*	55mm	
IST-11WM-K60*	60mm	
IST-11WM-K65*	65mm	
IST-11WM-K70*	70mm	
IST-11WM-K75*	75mm	
IST-11WM-K80*	80mm	
IST-11WM-K85*	85mm	
IST-11WM-K90*	90mm	
IST-11WM-K95*	95mm	
IST-11WM-K6A	6mm	IST-41WM200 IST-41WM340 (A×B 18×14mm)
IST-11WM-K7A	7mm	
IST-11WM-K8A	8mm	
IST-11WM-K9A	9mm	
IST-11WM-K10A	10mm	

型号	开口尺寸	适用的扳手
IST-11WM-K11A	11mm	IST-41WM200 IST-41WM340 (A×B 18×14mm)
IST-11WM-K12A	12mm	
IST-11WM-K13A	13mm	
IST-11WM-K14A	14mm	
IST-11WM-K15A	15mm	
IST-11WM-K16A	16mm	
IST-11WM-K17A	17mm	
IST-11WM-K18A	18mm	
IST-11WM-K19A	19mm	
IST-11WM-K20A	20mm	
IST-11WM-K21A	21mm	
IST-11WM-K22A	22mm	
IST-11WM-K23A	23mm	
IST-11WM-K24A	24mm	
IST-11WM-K25A	25mm	
IST-11WM-K30A*	30mm	
IST-11WM-K35A*	35mm	
IST-11WM-K40A*	40mm	
IST-11WM-K45A*	45mm	
IST-11WM-K50A*	50mm	
IST-11WM-K55A*	55mm	
IST-11WM-K60A*	60mm	
IST-11WM-K65A*	65mm	
IST-11WM-K70A*	70mm	
IST-11WM-K75A*	75mm	
IST-11WM-K80A*	80mm	
IST-11WM-K85A*	85mm	
IST-11WM-K90A*	90mm	
IST-11WM-K13B	13mm	IST-41WM500 IST-41WM650 IST-41WM800 IST-41WM1000 (A×B 32×24mm)
IST-11WM-K14B	14mm	
IST-11WM-K15B	15mm	
IST-11WM-K16B	16mm	
IST-11WM-K17B	17mm	
IST-11WM-K18B	18mm	
IST-11WM-K19B	19mm	
IST-11WM-K20B	20mm	
IST-11WM-K21B	21mm	
IST-11WM-K22B	22mm	
IST-11WM-K24B	24mm	
IST-11WM-K25B	25mm	
IST-11WM-K26B	26mm	
IST-11WM-K27B	27mm	
IST-11WM-K28B	28mm	
IST-11WM-K29B	29mm	
IST-11WM-K30B	30mm	

型号	开口尺寸	适用的扳手
IST-11WM-K32B	32mm	IST-41WM500 IST-41WM650 IST-41WM800 IST-41WM1000 (A×B 32×24mm)
IST-11WM-K35B*	35mm	
IST-11WM-K40B*	40mm	
IST-11WM-K45B*	45mm	
IST-11WM-K50B*	50mm	
IST-11WM-K55B*	55mm	
IST-11WM-K60B*	60mm	
IST-11WM-K65B*	65mm	
IST-11WM-K70B*	70mm	
IST-11WM-K75B*	75mm	
IST-11WM-K80B*	80mm	IST-41WM1500 IST-41WM2000 IST-41WM3000 (A×B 36×27mm)
IST-11WM-K85B*	85mm	
IST-11WM-K95B*	95mm	
IST-11WM-K17C	17mm	
IST-11WM-K18C	18mm	
IST-11WM-K19C	19mm	
IST-11WM-K20C	20mm	
IST-11WM-K22C	22mm	
IST-11WM-K24C	24mm	
IST-11WM-K26C	26mm	
IST-11WM-K27C	27mm	
IST-11WM-K28C	28mm	
IST-11WM-K29C	29mm	
IST-11WM-K30C	30mm	
IST-11WM-K32C	32mm	
IST-11WM-K34C	34mm	
IST-11WM-K36C	36mm	
IST-11WM-K38C	38mm	
IST-11WM-K40C	40mm	
IST-11WM-K41C	41mm	
IST-11WM-K42C	42mm	
IST-11WM-K44C	44mm	
IST-11WM-K45C	45mm	
IST-11WM-K46C	46mm	
IST-11WM-K50C*	50mm	
IST-11WM-K55C*	55mm	
IST-11WM-K60C*	60mm	
IST-11WM-K65C*	65mm	
IST-11WM-K70C*	70mm	
IST-11WM-K75C*	75mm	
IST-11WM-K80C*	80mm	
IST-11WM-K85C*	85mm	
IST-11WM-K90C*	90mm	
IST-11WM-K95C*	95mm	
IST-11WM-K100C*	100mm	

* 更换头部后需要重新调节扭矩值

可选配件

非标扳手头部	根据客户要求定制
--------	----------